



# Contaminant Reporting in Amine Gas Treating Service

By Randy Haws and Jim Jenkins

CCR Technologies Inc.  
11375 West Sam Houston Pkwy South  
Suite 201  
Houston, Texas 77031

## **ABSTRACT**

For a number of years the gas treating and refining industries have been focusing on Heat Stable Salts (HSS) contamination in amine service. As knowledge continues to improve in this area, amine system efficiencies are improved and turnaround cycles are minimized. However, two unfortunate states still exist in the industry: (1) analytical reporting for HSS is not consistent and is often times confusing to operators, and (2) HSS is only one of the major contaminants in a gas treating solution. A better understanding of the full range of contaminants and degradation products is essential to achieving total solvent quality. This paper will review current reporting and terminology so that confusion in analyzing contaminants and sample results may be minimized.

## **INTRODUCTION**

There is a wealth of literature available in the industry on the corrosive nature and proper control targets for Heat Stable Salts (HSS).<sup>1-4</sup> Unfortunately it is easy to be confused about measured levels and reporting terminology of these HSS anions. This confusion is compounded by the fact that comparing these measured values to proper control points may be difficult if they are not compared on a consistent basis. HSS are also generally only a part of the contaminants present in the gas treating solution so, it is important to understand the total level of contaminants and degradation products present in the processing solution. This is important for the operator to know because, as the level of contaminants and degradation products increase, the physical properties of the solution may change. As the physical properties of the solution change there may be the potential for increased operational issues, increased corrosion concerns, and an increase in degradation rates.

Here we will talk about what a *complete amine analysis* should look like so that we may fully understand the total level of contaminants in the gas treating solution. We will list general items to be measured in any gas treating solution, as well as review specific degradation products for specific amine types. We will also show how a full material balance, a nitrogen balance, and an amine balance may dictate when a more detailed analysis is warranted. We do this since not all solvent analysis is the same and also because the cost associated with a more detailed analysis often needs justification.

As an addendum, we will also give some industry recognized control points for the contaminants and degradation products that we discuss in the body of the paper.

### **CONTAMINANTS AND DEGRADATION PRODUCTS - DEFINED**

There are many compounds present in gas treating solutions circulating in process plants. Throughout the industry there has been a lot of focus on HSS while often the rest of the contaminants and degradation products are ignored. However often times these HSS anions may be only a portion of the total contaminants present in the solution and it is prudent to look at the total level of contaminants and degradation products. We like to refer to the total level of contaminants and degradation products in the solution as the *residue* of the solution. The residue of the solution is the amount of material that is generally not considered part of a healthy gas treating solution, meaning anything that is not free (active) amine or water. This residue, as equation 1 shows, is easy to calculate and encompasses all of the contaminants and degradation products present in the sample.

$$\text{Wt\% Residue} = 100 - \text{Wt\% Free Amine (FA)} - \text{Wt\% Water} \quad (1)$$

The residue is the total level of the contaminants and degradation products present in the sample. Contaminants and Degradation Products may be defined as follows:

#### **Contaminants**

Contaminants are items that enter the process and “pollute” the amine. These items would generally include solids/particulates, hydrocarbon, process chemicals, strong cations (sodium), HSS (from their precursors entering with the gas), and degradation products.<sup>5</sup>

#### **Degradation Products**

Degradation Products are contaminants in solution that are derived from reactions with the base amine molecule itself, where the molecule is broken down or changes chemical form. Many of these compounds are the result of irreversible degradation of the base amine molecule; ethylenediamine derivatives (THEED in the case of DEA and HEEU in the case of MEA) would be examples of this. Some of these compounds are the results of a reversible reaction or chemical equilibrium with the base amine molecule; formamides in the case of primary and secondary amines and BHEEU in the case of DGA® would be examples of this.

For optimized unit operations, it is important to know and understand the total level of residue including all contaminants and degradation products. It is also important to understand the characteristics of the residue for evaluating concerns for unit operation, concerns for corrosion, and for evaluating merchant reclaiming options when necessary.

### **BASIC AMINE ANALYSIS FOR BULK COMPOSITION MATERIAL BALANCE**

There are basic items that should be measured in every sample regardless of the amine type. These items are generally used as good control points for optimized unit operation, and may also be used to decide whether or not a more detailed analysis of the solution may be warranted. These items include:

#### **1. Alkalinity**

Alkalinity may be measured directly using a simple titration, and is the amount of “Free Amine” in the solution. The Amine content of the solution may be represented by equation 2.

$$\text{FA} + \text{BA} = \text{TA} \quad (2)$$

FA = Free Amine  
BA = Bound Amine  
TA = Total Amine

The FA is the amine that is available for acid gas pickup. The BA is the amine that is no longer available for acid gas pickup. TA is the total amine in the sample.

Alkalinity is also very often referred to as the “Amine Strength”. Alkalinity is a good control point for proper solvent performance, since it is the measurement of the material available for acid gas pickup. A low alkalinity indicates that circulation may be higher than design in order to compensate for the reduced acid gas pickup of the solvent. A high alkalinity may exacerbate corrosion, and lead to operational problems due to changes in the physical properties of the solvent.

## 2. Water

Water is a very important item, should be measured directly, and should have a minimum control target. This measurement is necessary for the bulk composition material balance of the sample to show sample recovery, and to calculate the residue of the sample. Water also plays a critical role in determining the actual physical properties of the solvent.<sup>6</sup> When water content becomes too low, solvent quality and unit operation become concerns.

## 3. Loading

Loadings are measured to ensure that the solvent is operating within recognized industry guidelines. A high lean loading indicates that the solvent is not being stripped properly. This may be due to improper process conditions or equipment damage or fouling. A high lean loading will also reduce your net acid gas pickup provided the rich loading stays within guidelines. A low lean loading indicates that the unit is not configured for optimal energy consumption, and over stripping may exacerbate corrosion.

We recommend that H<sub>2</sub>S and CO<sub>2</sub> be measured separately since changes in H<sub>2</sub>S/CO<sub>2</sub> ratio may warrant process changes and increased concern for corrosion. A change in this ratio may also indicate an accumulation of degradation products affecting solvent performance such, as the accumulation of MDEA fragments in Tail-Gas-Treater (TGTU) service.<sup>7</sup>

## 4. Strong Acid Anions

Strong Acid Anions is another name for Heat Stable Salt (HSS) anions in the gas treating solvent. These HSS anions may be speciated (see Appendix 4) to give a total, or a titration may be completed to give the total. It is important to measure all of the anions *directly* since targets are set on these HSS anions to help minimize the corrosion potential of the solvent.

It is important to understand that HSS anions may be reported at least three different ways, and it is important to understand the methodology employed to avoid confusion.

### HSS Anions – Weight Percent of Solution

HSS Anions (Strong Acid Anions) measured as weight percent of the total solution.

HSS Anions – Expressed As Weight Percent Amine

HSS Anions listed as weight percent of the amine. Meaning, if the anion is bound to an amine molecule, what is the amount of amine expressed as weight percent of the total solution.

HSS Anions – Expressed As Percent of Amine Capacity (As Percent Total Amine)

HSS expressed as weight percent amine divided by the amine strength (Free Amine or Alkalinity).

An example of these different reporting methods for MDEA:

Amine Strength wt%	30.5
HSS Anions wt%	5.33
HSS Anions as wt% MDEA	13.13
HSS Anions as Percent Amine Capacity	43.05

MDEA MW = 119

HSS Anion MW = 48.2

**5. Strong Cations**

This is the amount of strong cations (Sodium and Potassium) in the gas treating solvent. It is important to measure these items to facilitate calculating the sample recovery and the amount of Bound Amine

**6. Bound Amine**

This is the amount of amine that is “bound” by the HSS anions in solution, and may also be referred to as a Heat Stable Amine Salt (HSAS). This value may be measured directly or may be calculated using the amount of Strong Acid Anions and Strong Cations in solution. Bound Amine (HSAS) *does not equal* HSS anions since Bound Amine (HSAS) is just the amount of amine unavailable for acid gas removal. HSS anions may form a salt with a strong cation or a protonated amine molecule. Therefore it is important to understand the difference between HSS anions and Bound Amine (HSAS).

The amine solution in the system has to be electronically balanced based on equation 3.

$$\Sigma \text{Cations} = \Sigma \text{Anions} \quad (3)$$

Related to the chemical constituents in the amine system, equation 3 may be expressed as follows:

$$\Sigma (\text{Bound Amine}) + (\text{Strong Cations}) = \Sigma (\text{HSS Anions}) + (\text{Lean Loading}) \quad (4)$$

Bound Amine = Protonated Amine Molecule

Strong Cations = Na<sup>+</sup>, K<sup>+</sup>

HSS Anions = Heat Stable Salt anions (acetates, formates, thiosulfates, etc.)

Lean Loading = HS<sup>-</sup>, HCO<sub>3</sub><sup>-</sup>

Often companies will report the Heat Stable Salt (HSS) level as equal to the amount of bound amine in solution. This practice simplifies the analysis, but as demonstrated in equation 4, is not technically correct. Strong cation levels will affect the HSS level in relationship with the bound amine; that is why we urge caution here.

## 7. Recovery

The above six items are the minimum requirements for any gas treating solution to investigate the condition of the solvent. These items may be added together on a consistent basis (wt% of solution) to see how close to 100% the results have come. Poor recovery, or poor closure of the material balance may indicate that further analysis is necessary. Obviously there are other items that should be added to the list for sample recovery that are amine specific, and we will cover those under each amine type. A recovery greater than 95 percent should be adequate for monitoring purposes. A sample recovery less than 95 percent should be cause for some concern and further analysis may be warranted, particularly if operating problems or corrosion concerns are issues at the plant.

## AMINE SPECIFIC DEGRADATION PRODUCT ANALYSIS

There are additional items that should be measured to further understand the solvent quality and increase the percent of the sample recovery for each of the amine types. A few of these for the various amines would be:

### MEA

#### 1. Formamides

N-formyl amines (formamides) are degradation products generally found in gas treating solutions that are based on primary and secondary amines.<sup>8</sup> Under certain conditions primary and secondary amines react with the formic acid in solution (via dehydration) to form n-formyl amines.

The data from process solutions containing formate as a Heat Stable Salt (HSS) anion shows that there is an equilibrium relationship that exists between the amount of formate HSS in solution and the amount of MEA-F in solution.<sup>9</sup> See the equation 5 below.



Since the above equation represents equilibrium, it is then possible to also hydrolyze MEA-F back into MEA and formic acid. The heat and water present in the stripper of the amine unit will generate a new equilibrium if the balance of the equation is disturbed by removing one of the above components.

#### 2. HEED

Hydroxyethylethylenediamine (HEED) is a well-known degradation product of MEA from reactions with CO<sub>2</sub>. There is a wealth of literature on the reaction mechanisms and the corrosive nature of HEED.<sup>5</sup> While much of the literature has focused on MEA in CO<sub>2</sub> service only, HEED has been found in combined refinery systems treating H<sub>2</sub>S and CO<sub>2</sub>. While it may not be the main degradation product in refinery amine systems, it must be monitored and removed from the system due to its corrosive nature.

#### 3. HEEU

Hydroxyethylethyleneurea (HEEU) is a degradation product of MEA that is not that well known since most of the literature has focused on degradation in CO<sub>2</sub> service. HEEU is formed via the same reaction pathway as HEED when COS is present in the gas.<sup>10</sup> COS is generally present in combined refinery treating systems where FCC, Coker and other

cracking/conversion units are employed in the plant configuration. HEEU has been found to be one of the main degradation products in refinery amine systems.

### **DGA®**

#### **1. Formamides**

Same as MEA above.

#### **2. BHEEU**

N,N bis(hydroxyethoxy-ethyl)urea (BHEEU) is an inert degradation product formed in the presence of COS and CO<sub>2</sub>.<sup>10</sup> BHEEU is a degradation product that is reversible with thermal reclaiming.

#### **3. Morpholine**

This is an inert degradation product, which however rare, can occur when the solution is subjected to high temperatures.

### **DEA**

#### **1. Formamides**

Same as MEA above.

#### **2. THEED**

Tris-hydroxyethyl ethylenediamine (THEED) is a well-known degradation product of DEA from reactions with CO<sub>2</sub>. There is a wealth of literature on the reaction mechanisms and the corrosive nature of THEED.<sup>5,10</sup> While much of the literature has focused on DEA in CO<sub>2</sub> service only, THEED has been found in combined refinery systems treating H<sub>2</sub>S and CO<sub>2</sub>. While it may not be the main degradation product in refinery amine systems, it must be monitored and removed from the system due to its corrosive nature.

#### **3. Bis-HEP**

Bis-hydroxyethyl piperazine (bis-HEP) is a well-known degradation product of DEA from reactions with CO<sub>2</sub>. There is a wealth of literature on the reaction mechanisms of bis-HEP.<sup>5,10</sup> While much of the literature has focused on DEA in CO<sub>2</sub> service only, bis-HEP has been found in combined refinery systems treating H<sub>2</sub>S and CO<sub>2</sub>. While bis-HEP is not considered corrosive and it does have some base strength, it needs to be removed from the circulating system to optimize water content and active amine levels.

#### **4. MEA**

In the presence certain chemical compounds or intermediates, it is possible to degrade or break down the DEA molecule to simpler amines. Monoethanolamine (MEA) is one of the simpler amines that may be formed from DEA degradation. It is important to monitor the level of MEA in the circulating DEA system due to Amine Stress Corrosion Cracking (ASSC) concerns associated with MEA.

#### **5. Bicine**

Bis-(hydroxyethyl) glycine (Bicine) is degradation product formed in the presence of DEA and unstable chemical intermediates, and is considered corrosive.

### **MDEA**

#### **1. MDEA Fragments**

MDEA in TGTU and in some primary amine system service should be monitored for MDEA fragments. These include MMEA, DEA, Bicine and C2+ HSS anions.<sup>7</sup>

## 2. Special Considerations For Formulated MDEA

Depending upon the formulating agent, MDEA may need to be monitored for degradation products listed for MEA and DEA listed above. We recommend discussing this with your amine supplier if your sample recovery is low.

### AMINE AND NITROGEN BALANCES

It is very difficult to get 100% recovery of a sample and it is often necessary to understand what the unknowns are in solution without spending thousands of dollars for subsequent analysis. These balance calculations are very useful when you are trying to understand your total contaminant level and further evaluate the nature of the degradation in your sample

#### **Excess Amine**

An amine balance takes the measured amine strength (alkalinity) and subtracts the actual amounts of the amine that you are utilizing in the plant (amine specifically identified). In DEA systems, for example, you will take the measured amine strength and subtract out the identified DEA in the sample. The excess amine is material that has base strength, but is not a DEA molecule. Certain degradation products of DEA (THEED and Bis-HEP) have base strength but do not perform as well in removing acid gas as DEA.<sup>11</sup> THEED is also considered corrosive, so there are additional concerns with it.

#### **Excess Nitrogen**

A nitrogen balance measures the total amount of nitrogen in your sample then subtracts the amount of nitrogen that was identified from the components measured in the sample. Any excess nitrogen in the sample is generally from high molecular weight, high boiling point degradation products (polymeric material).<sup>5</sup>

#### **Compounds that Will Analyze as Excess Amine - DEA**

<b>THEED</b>	Base	Corrosive
<b>Bis-HEP</b>	Base	Non-Corrosive
<b>Polymeric Material (Low molecular weight analogs of THEED)</b>	Base	Non-Corrosive
<b>Polymeric Material (Higher molecular weight analogs of THEED)</b>	Base	Non-Corrosive

#### **Compounds that Will Analyze as Excess Nitrogen - DEA**

<b>Polymeric Material (Higher molecular weight analogs of THEED)</b>	Inert	Non-Corrosive
<b>Formamide (DEAF or NFDEA)</b>	Inert	Non-Corrosive
<b>HEOXD (HE Oxazolidone)</b>	Inert	Non-Corrosive
<b>Bicine (bis-(hydroxyethyl) glycine)</b>	Inert	Corrosive

Appendix 1 contains similar tables for the other common amines.

### EXAMPLES OF COMPLETE AMINE ANALYSIS

There have been many times when an incomplete sample analysis or confusion over the terminology of the sample results have led to problems for plant operators. There have been cases of extreme unit fouling, severe operational problems, and solvent reclamation cost escalation. We would like to show examples of how a *complete sample analysis* or clearer

understanding of the results would have indicated a potential problem or would have given a better understanding of issues surrounding the analysis of available reclaiming technology and price structure.

### 1. MEA – Refinery Service

<b>MEA Customer</b>		
<b>Analytical Results</b>		
Amine Type	MEA	<b>Alternate Units/Notes</b>
Amine Strength wt%	10.74	
Water wt%	42.10	
H2S wt%	0.00	
CO2 wt%	0.01	
Strong Acid Anions wt%	6.28	
Strong Cations wt%	0.01	Percent Neutralization → 0
Bound Amine wt%	7.36	Calculated
Formamides wt%	4.95	
HEED wt%	na	
HEEU wt%	8.19	
Other wt%	na	
<b>Percent Recovery</b>	<b>79.63</b>	
<b>Organic Acids</b>		
Formate ppm	23300	
Acetate ppm	2764	
Oxalate ppm	796	
Lactate ppm	503	
Glycolate ppm	nd	
Propionate ppm	393	
Butyrate ppm	na	
<b>Total ppm</b>	<b>27756</b>	
<b>Inorganic Acids</b>		
Chloride ppm	16	
Sulfate ppm	308	
Sulfite ppm	nd	
Thiosulfate ppm	22753	
Thiocyanate ppm	11921	
Phosphate ppm	na	
<b>Total ppm</b>	<b>34998</b>	
<b>Total HSS Anions ppm</b>	<b>62754</b>	
<b>Total HSS Anions wt%</b>	<b>6.28</b>	
<b>HSS as wt% Amine</b>	<b>7.38</b>	
<b>HSS as Percent Amine Capacity</b>	<b>68.68</b>	

Three different ways to express the value of the HSS Anions.

Example - MEA

This plant operator utilizes MEA in a refinery primary amine treating system for specific reasons. The gas being treated in this unit had high levels of Carbonyl Sulfide (COS), so MEA was selected due to its reaction rate kinetics with COS. The gas being treated also had variable levels of Oxygen, so MEA was selected since it is a simple amine with slower degradation rates in the presence of oxygen. Because of MEA degradation due to oxygen and to the level of HSS precursors in the gas, a slipstream thermal reclaimer was necessary for optimal unit operation.

When the unit was started up it did perform well and fuel gas specifications could be met. Unfortunately over time it became apparent that the reclaimer was undersized since it had a hard time controlling the level of HSS anions in solution. Also over time gas rates dropped since there were some fouling

issues surrounding the process equipment. Some equipment changes were made and fouling issues were somewhat minimized, but were still a concern.

Since the plant was using HSS anions as a control point for their reclaimer operations, they did not measure much else in the solution on a frequent basis. They elected to try using ion exchange to remove the HSS anions thinking that this would greatly improve unit operations. Ion exchange was effective at removing the HSS anions, but over time the unit fouling became worse and unit operation began to suffer. A decision was made to look at a *complete sample analysis*, which ended up surprising the plant operator.



<b>MEA Customer</b>	
<b>Residue Calculation</b>	
Amine Strength wt%	10.74
Water wt%	42.10
H2S wt%	0.00
CO2 wt%	0.01
} → Water, Active Amine, and Residual Lean Loading are the expected items in a healthy gas treating solvent.	
Strong Acid Anions wt%	6.28
Strong Cations wt%	0.01
Bound Amine wt%	7.36
Formamides wt%	4.95
HEED wt%	na
HEEU wt%	8.19
Other wt%	na
Un-Recovered	20.37
} → These remaining items in the solution are what we refer to as residue or the total contaminants in the system. These are the items that need to be controlled in the solution for optimal unit operation.	
<b>Total Residue</b>	<b>47.15</b>
<b>Excess Nitrogen</b>	<b>13.6</b>
<b>Excess Amine</b>	<b>1.9</b>
<b>Example - MEA</b>	

As can be seen from the complete sample analysis, the sample recovery is very low at around 80 percent, meaning that with even a fairly complete sample analysis we still could not account for 20 percent of the contaminants and degradation products in the sample. As we mentioned before, the plant operator was very surprised since they thought that they had between 6 to 8 percent HSS and nothing else in the sample. The amount of residue in this sample was about 47 percent, so that while the plant had accounted for 7 percent HSS there was a significant number of other contaminants and

degradation products accounting for about 40 percent of the circulating solution. We immediately began to understand that this amount of residue could account for many of the operating problems experienced at this facility.

The analytical results, and residue calculation and amine and nitrogen balances all showed that HSS were only a small portion of the concern surrounding the solvent quality. HEEU was high due to the fact that there was a high level of COS in the gas. Even though HEEU is a high boiler and may be controlled in a conventional thermal reclaimer, the undersized reclaimer was not able to remove it adequately. As the level of contaminants and degradation products increased in this sample the water content of the solution dropped. As the water level decreased, the solution properties began to change (i.e. viscosity, mass transfer rates, boiling point) and the reaction rates of the degradation products increased since they are dehydration reactions catalyzed by heat. This exacerbated unit operations problems and the degradation of the solvent over time. Since the nitrogen imbalance was very high, we can see from referencing Appendix 1 that there were also increased concerns over the fouling potential of the solvent due to polymeric material.

This case shows that it is very important to understand the total level of contaminants and degradation products in the circulating solution. Also it is important to understand how conventional thermal slipstream reclaiming or merchant reclaiming technologies may or may not improve the *total quality* of the solvent. The residue of this sample may have been controlled using adequately sized conventional thermal reclaiming. The residue of this sample may not have been substantially improved using ion exchange technology since the HSS anions were a very small part of the circulation solution. This plant operator had to decide whether or not to dump and replace the solution or choose a reclaiming technology with the capability to improve total solvent quality.

2. DEA – Refinery Service

<b>DEA Customer</b>		
<b>Analytical Results</b>		
Amine Type	DEA	<b>Alternate Units/Notes</b>
Amine Strength wt%	23.65	
Water wt%	67.20	
H2S wt%	0.00	
CO2 wt%	0.00	
Strong Acid Anions wt%	2.14	
Strong Cations wt%	0.49	Percent Neutralization → 49
Bound Amine wt%	2.29	Calculated
Formamides wt%	2.64	
THEED wt%	na	
bis-HEP wt%	na	
Bicine wt%	0.17	
Other wt%	na	
<b>Percent Recovery</b>	<b>98.58</b>	
<b>Organic Acids</b>		
Formate ppm	11862	
Acetate ppm	510	
Oxalate ppm	nd	
Lactate ppm	360	
Glycolate ppm	nd	
Propionate ppm	89	
Butyrate ppm	na	
<b>Total ppm</b>	<b>12821</b>	
<b>Inorganic Acids</b>		
Chloride ppm	700	
Sulfate ppm	382	
Sulfite ppm	nd	
Thiosulfate ppm	nd	
Thiocyanate ppm	7469	
Phosphate ppm	na	
<b>Total ppm</b>	<b>8551</b>	
<b>Total HSS Anions ppm</b>	<b>21372</b>	
<b>Total HSS Anions wt%</b>	<b>2.14</b>	} → Three different ways to express the value of the HSS Anions.
<b>HSS as wt% Amine</b>	<b>4.52</b>	
<b>HSS as Percent Amine Capacity</b>	<b>19.10</b>	

Example - DEA

This plant operator utilizes DEA in a refinery primary amine treating system and generally experiences excellent operational reliability. This plant does a very good job of controlling their HSS levels to ensure reliability due to problems that they have had in the past. Since the customer asked us to help them evaluate the total cost associated with reclaiming their solution, we looked at a *complete sample analysis*. The customer had utilized ion exchange and vacuum distillation in the past and wanted to understand two things, 1) would the level of sodium in the sample affect the processing cost and 2) does the formamide (DEAF) affect the processing cost.

The solution analysis showed that about 50 percent of the HSS anions were neutralized with a strong cation, which in this case was sodium. Therefore based on equation 4 showing that the solution must be electronically balanced, we had to look to

see if sodium had to be removed to attain the desired HSS endpoint. Based on a HSS anion endpoint of 0.5 wt%, the strong cation level would have to be reduced to at least 0.23 wt% so that the solution was not “over neutralized”. This indicated that the chosen reclaiming technology would have to be able to remove the strong cations as well as the HSS anions, and the cost associated with this had to be accounted for in understanding how each technology charged for removal.

The level of formamides did indicate that it would also have to be included in any processing cost evaluation for the reclaiming job. Based on equation 5, we see that by removing the formate HSS anion, the DEAF would reconvert to DEA and formic acid. This formic acid generated would then also have to be removed once a new equilibrium was established. Therefore the plant had to understand how each technology charged for removal, based on slipstream processing while the unit was on line. If batch processing was employed, then we also advised the customer that it

would then be important to understand the removal efficiency of each technology on a once through the chosen reclaiming unit basis.

<b>DEA Customer</b>	
<b>Residue Calculation</b>	
Amine Strength wt%	23.65
Water wt%	67.20
H2S wt%	0.00
CO2 wt%	0.00
<div style="border: 1px solid black; padding: 5px; margin-top: 10px;">                     Water, Active Amine, and Residual Lean Loading are the expected items in a healthy gas treating solvent.                 </div>	
Strong Acid Anions wt%	2.14
Strong Cations wt%	0.49
Bound Amine wt%	2.29
Formamides wt%	2.64
THEED wt%	na
bis-HEP wt%	na
Bicine wt%	0.17
Other wt%	na
Un-Recovered	1.42
<div style="border: 1px solid black; padding: 5px; margin-top: 10px;">                     These remaining items in the solution are what we refer to as residue or the total contaminants in the system. These are the items that need to be controlled in the solution for optimal unit operation.                 </div>	
<b>Total Residue</b>	<b>9.15</b>
<b>DEA Fragments</b>	
MEA wt%	0.07
C2+ Acids wt%	0.10
Bicine wt%	0.17
<b>Total</b>	<b>0.34</b>
<b>Excess Nitrogen</b>	<b>1.7</b>
<b>Excess Amine</b>	<b>1.4</b>
Example - DEA	

The amine and nitrogen balances from this sample show that there were some additional degradation products present in the sample (refer to Appendix 1). We also recommended that the customer consider the nature of these degradation products and how each reclaiming technology will affect their removal from the solution.

This is another example of why understanding more than the HSS levels in solution is very important. While this customer does take great efforts to keep their solvent relatively clean, it was very important for them to look at and understand the effects of the sodium, DEAF and the excess amine and nitrogen measured in the sample analysis.

### 3. MDEA – Refinery Service

This plant operator utilizes MDEA in a refinery primary amine treating system and generally experiences excellent operational reliability. This plant started to experience some fouling and corrosion concerns and were puzzled since they thought that their HSS levels were fairly low. We decided to look at a *complete sample analysis* to see if this would show us anything.

<b>MDEA Customer</b>		
<b>Analytical Results</b>		
		<b>Alternate Units/Notes</b>
<b>Amine Type</b>	MDEA	
<b>Amine Strength wt%</b>	30.50	
<b>Water wt%</b>	60.30	
<b>H2S wt%</b>	0.03	
<b>CO2 wt%</b>	0.00	
<b>Strong Acid Anions wt%</b>	5.33	
<b>Strong Cations wt%</b>	2.46	97 Percent Neutralization
<b>Bound Amine wt%</b>	0.41	Calculated
<b>Formamides wt%</b>	na	
<b>THEED wt%</b>	na	
<b>bis-HEP wt%</b>	na	
<b>Bicine wt%</b>	0.03	
<b>Other wt%</b>	na	
<b>Percent Recovery</b>	99.06	
<b>Organic Acids</b>		
<b>Formate ppm</b>	37411	
<b>Acetate ppm</b>	2026	
<b>Oxalate ppm</b>	50	
<b>Lactate ppm</b>	246	
<b>Glycolate ppm</b>	nd	
<b>Propionate ppm</b>	nd	
<b>Butyrate ppm</b>	na	
<b>Total ppm</b>	39733	
<b>Inorganic Acids</b>		
<b>Chloride ppm</b>	214	
<b>Sulfate ppm</b>	285	
<b>Sulfite ppm</b>	nd	
<b>Thiosulfate ppm</b>	485	
<b>Thiocyanate ppm</b>	12533	
<b>Phosphate ppm</b>	na	
<b>Total ppm</b>	13517	
<b>Total HSS Anions ppm</b>	53250	} → Three different ways to express the value of the HSS Anions.
<b>Total HSS Anions wt%</b>	5.33	
<b>HSS as wt% Amine</b>	13.13	
<b>HSS as Percent Amine Capacity</b>	43.05	

This customer thought that they had a HSS level of anywhere between 0.5 and 1 percent as MDEA. The sample analysis showed that the bound amine (or HSAS) was rather low at 0.41 percent. However the HSS anion analysis showed that the level of HSS anions expressed as MDEA were at a level of 13.13 percent. The analysis showed that there was a high level of strong cations, which effectively neutralized 97 percent of the HSS anions as a sodium salt, (refer to equation number 4). It was speculated that the high level of sodium salts associated with the HSS anions was contributing to the fouling problem. This high HSS anion level could also be accelerating corrosion rates in the system, with the resulting corrosion by-products contributing to the fouling of the unit.

<b><u>MDEA Customer</u></b>	
<b>Residue Calculation</b>	
<b>Amine Strength wt%</b>	30.50
<b>Water wt%</b>	60.30
<b>H2S wt%</b>	0.03
<b>CO2 wt%</b>	0.00
	} →
	Water, Active Amine, and Residual Lean Loading are the expected items in a healthy gas treating solvent.
<b>Strong Acid Anions wt%</b>	5.33
<b>Strong Cations wt%</b>	2.46
<b>Bound Amine wt%</b>	0.41
<b>Formamides wt%</b>	na
<b>THEED wt%</b>	na
<b>bis-HEP wt%</b>	na
<b>Bicine wt%</b>	0.03
<b>Other wt%</b>	na
<b>Un-Recovered</b>	0.94
	} →
	These remaining items in the solution are what we refer to as residue or the total contaminants in the system. These are the items that need to be controlled in the solution for optimal unit operation.
<b><u>Total Residue</u></b>	<b><u>9.17</u></b>
<b><u>MDEA Fragments</u></b>	
<b>DEA wt%</b>	0.37
<b>MMEA wt%</b>	0.20
<b>C2+ Acids wt%</b>	0.23
<b>Bicine wt%</b>	0.03
<b><u>Total</u></b>	<b><u>0.83</u></b>
<b><u>Excess Nitrogen</u></b>	<b><u>3.1</u></b>
<b><u>Excess Amine</u></b>	<b><u>1.2</u></b>
<b>Example - MDEA</b>	

The sample analysis showed that there was also some excess nitrogen in the sample, which could also potentially be causing some of the fouling problems. A recommendation was made to improve the solvent quality by lowering the level of strong cations, HSS anions and the degradation products showing up as excess nitrogen.

### **SUMMARY**

Please refer to Appendix 2 for industry recognized guidelines for proper solvent quality. When trying to troubleshoot operational issues at a plant, a *complete sample analysis* is a very valuable tool. Trending of analytical data is also very helpful for noting changes in operation and measured corrosion rates. The material presented here is intended as an aid in understanding the analysis and the meaning of the results. It is important

when evaluating your results versus industry standards to use "voting" type logic. If one parameter is high immediate action may not be necessary, rather it is helpful to look at all of the solution parameters to see how they all compare to industry guidelines. While industry guidelines for solvent quality control are very helpful, it is important to understand that measurements within acceptable ranges do not guarantee reliable operation, nor do measurements outside of acceptable ranges guarantee imminent problems. Rather, these guidelines are simply that: guidelines for monitoring and evaluation of your system. Remember that if you are considering reclaiming you need to understand the characteristic of the residue and how each reclaiming technology removes these compounds. This will ensure that you are not disappointed with the final solvent quality and are not surprised by the final cost of the job. Please see Appendix 3 for summary of common contaminants for each amine type and merchant reclaiming effectiveness at removing these compounds.

**REFERENCES**

1. Rooney, P. C., T. R. Bacon and M. S. Dupart, "Effect of Heat Stable Salts on MDEA Solution Corrosivity", Hydrocarbon Processing, March 1996.
2. Liu, H. J., J. W. Dean and S. F. Bosen, "Neutralization to Reduce Corrosion from Heat Stable Amine Salts", Corrosion95, Paper No. 572, 1995.
3. Cummings, A. L., F. C. Veatch and A. E. Keller, "Corrosion and Corrosion Control Methods in Amine Systems Containing H<sub>2</sub>S", Corrosion97, Paper No. 341, 1997.
4. Meisen, A., M. Abedinzadegan, R. Abry and M. Millard, "Degraded Amine Solutions: Nature, Problems and Distillative Reclamation", Proceedings of the 1996 Laurance Reid Gas Conditioning Conference.
5. McCullough, J. G., and R. B. Nielsen, "Contamination and Purification of Alkaline Gas Treating Solutions", Corrosion96, Paper No. 396, 1996.
6. Cheng, S., A. Meisen and A. Chakma, "Predict Amine Solution Properties Accurately", Hydrocarbon Processing, February 1996.
7. Critchfield, J. E. and J. L. Jenkins, "Evidence of MDEA Degradation in Tail Gas Treating Plants", Petroleum Technology Quarterly, Spring 1999.
8. Koike, et al, "N-Formyldiethanolamine: A New Artefact(sic) in Diethanolamine Solutions", Chemistry & Industry, 1987.
9. Huntsman Corporation Technical Training, "Evidence of Empirical Equilibrium Between Formate and n-Formyl Amines in Gas Treating Application", 1999.
10. Kohl, A. and R. Nielsen, "Gas Purification" 5<sup>th</sup> Edition, Gulf Publishing, Houston, 1997, pp. 236-239.
11. Holub, P. E., J. E. Critchfield and W. Y. Su, "Amine Degradation Chemistry in CO<sub>2</sub> Service", Proceedings of the 1998 Laurance Reid Gas Conditioning Conference.

**ADDITIONAL SOURCES**

1. Nielsen, R. B., K. R. Lewis, J. G. McCullough and D. A. Hansen, "Corrosion in Refinery Amine Systems", Corrosion95, Paper No. 571, 1995.
2. Craig, H. L. and B. D. McLaughlin, "Corrosive Amine Characterization", Corrosion96, Paper No. 394, 1996.
3. Fan, D., L. E. Kolp, D.S. Huett and M.A. Sargent, "Role of Impurities and H<sub>2</sub>S in Refinery Lean DEA System Corrosion", Corrosion2000, Paper No. 495, 2000.
4. Chakma, A. and A. Meisen, "Identification of Methyl Diethanolamine Degradation products By Gas Chromatography and Gas Chromatography-Mass Spectrometry", Journal of Chromatography, 457 (1998) 287-297.
5. Dawodu, O. F. and A. Meisen, "Identification of Products Resulting From Carbonyl Sulphide-Induced Degradation of Diethanolamine", Journal of Chromatography, 587 (1991) 237-246.
6. Kohl, A. and R. Nielsen, "Gas Purification" 5<sup>th</sup> Edition, Gulf Publishing, Houston, 1997, pp. 210-212, 232-269.

# Appendix 1

## Examples of MEA Degradation Products Containing Nitrogen

### Compounds that Will Analyze as Excess Amine

<b>HEED</b>	Base	Corrosive
<b>Polymeric Material (Low molecular weight analogs of HEED)</b>	Base	Non-Corrosive
<b>Polymeric Material (Higher molecular weight analogs of HEED)</b>	Base	Non-Corrosive

### Compounds that Will Analyze as Excess Nitrogen

<b>Polymeric Material (Higher molecular weight analogs of HEED)</b>	Inert	Non-Corrosive
<b>HEEU</b>	Inert	Non-Corrosive
<b>Formamide (MEAF or NFMEA)</b>	Inert	Non-Corrosive
<b>OX (Oxazolidone)</b>	Inert	Non-Corrosive

## Examples of DGA® Degradation Products Containing Nitrogen

### Compounds that Will Analyze as Excess Amine

<b>Morpholine</b>	Base	Inert
-------------------	------	-------

### Compounds that Will Analyze as Excess Nitrogen

<b>BHEEU</b>	Inert	Non-Corrosive
<b>Formamide (DGAF or NFDGA)</b>	Inert	Non-Corrosive

### Examples of DEA Degradation Products Containing Nitrogen

#### Compounds that Will Analyze as Excess Amine

<b>THEED</b>	Base	Corrosive
<b>Bis-HEP</b>	Base	Non-Corrosive
<b>Polymeric Material (Low molecular weight analogs of THEED)</b>	Base	Non-Corrosive
<b>Polymeric Material (Higher molecular weight analogs of THEED)</b>	Base	Non-Corrosive

#### Compounds that Will Analyze as Excess Nitrogen

<b>Polymeric Material (Higher molecular weight analogs of THEED)</b>	Inert	Non-Corrosive
<b>Formamide (DEAF or NFDEA)</b>	Inert	Non-Corrosive
<b>HEOXD (HE Oxazolidone)</b>	Inert	Non-Corrosive
<b>Bicine (bis-(hydroxyethyl) glycine)</b>	Inert	Corrosive

### Examples of MDEA Degradation Products Containing Nitrogen

#### Compounds that Will Analyze as Excess Amine

<b>DEA</b>	Base	Non-Corrosive
<b>MMEA</b>	Base	Non-Corrosive
<b>Polymeric Material (Low molecular weight analogs of THEED)</b>	Base	Non-Corrosive
<b>Polymeric Material (Higher molecular weight analogs of THEED)</b>	Base	Non-Corrosive

#### Compounds that Will Analyze as Excess Nitrogen

<b>Polymeric Material (Higher molecular weight analogs of THEED)</b>	Inert	Non-Corrosive
<b>Formamide (DEAF or NFDEA)</b>	Inert	Non-Corrosive
<b>Bicine (bis-(hydroxyethyl) glycine)</b>	Inert	Corrosive
<b>HE Sarcosine (hydroxyethyl methylglycine)</b>	Inert	Corrosive



## Appendix 2

### Solvent Quality Guidelines

#### MEA – Refining Service

Free Amine (Alkalinity)	20 wt% Max
Water	70 wt% Min.
HSS Anions	<2.5 Expressed as wt% as MEA <8.0 Percent Amine Capacity
Formamides (MEAF)	<3.0 wt%
HEED	<0.5 wt%
HEEU	<1.0 wt%
Excess Amine	Within Allowable Ranges
Excess Nitrogen	Within Allowable Ranges

#### DGA® – Refining Service

Free Amine (Alkalinity)	50 wt% Max
Water	40 wt% Min.
HSS Anions	<2.5 Expressed as wt% as DGA® <8.0 Percent Amine Capacity
Formamides (DGAF)	<3.0 wt%
BHEEU	<6.0 wt%
Excess Amine	Within Allowable Ranges
Excess Nitrogen	Within Allowable Ranges

#### DEA – Refining Service

Free Amine (Alkalinity)	30 wt% Max
Water	60 wt% Min.
HSS Anions	<2.5 Expressed as wt% as DEA <8.0 Percent Amine Capacity
Formamides (DEAF)	<3.0 wt%
THEED	<1.5 wt%
Excess Amine	Within Allowable Ranges
Excess Nitrogen	Within Allowable Ranges

#### MDEA – Refining Service

Free Amine (Alkalinity)	50 wt% Max
Water	40 wt% Min.
HSS Anions	<2.5 Expressed as wt% as MDEA <8.0 Percent Amine Capacity
MDEA Fragments	<2.5 wt%
Bicine	<0.4 wt%
Excess Amine	Within Allowable Ranges
Excess Nitrogen	Within Allowable Ranges

## Appendix 3

### MEA Contamination/Degradation In Refinery Service

HSS	Potentially Corrosive	Contaminant
Formamide (MEAF)	Non-Corrosive	Contaminant/Degradation
HEED	Potentially Corrosive	Degradation
HEEU	Non-Corrosive	Degradation
Polymeric Material	Non-Corrosive	Degradation

### MEA Solvent Quality Management With Merchant Reclaiming Options Vacuum Distillation, Ion Exchange, Electrodialysis

Control of HSS	All
Control of MEAF (Slip-Stream Processing)	All
Control of MEAF (Batch Processing)	Vacuum Distillation Only
Control of HEED	Vacuum Distillation Only
Control of HEEU	Vacuum Distillation Only
Control of Polymeric Material	Vacuum Distillation Only

Best Efficiency = Batch Processing

### DGA® Contamination/Degradation In Refinery Service

HSS	Potentially Corrosive	Contaminant
Formamide (DGAF)	Non-Corrosive	Contaminant/Degradation
BHEEU	Non-Corrosive	Degradation (Reversible)
Polymeric Material	Non-Corrosive	Degradation

### DGA® Solvent Quality Management With Merchant Reclaiming Options Vacuum Distillation, Ion Exchange, Electrodialysis

Control of HSS	All
Control of DGAF (Slip-Stream Processing)	All
Control of DGAF (Batch Processing)	Vacuum Distillation Only
Control of BHEEU	Vacuum Distillation Only
Control of Polymeric Material	Vacuum Distillation Only

Best Efficiency = Batch Processing

**DEA Contamination/Degradation In Refinery Service**

HSS	Potentially Corrosive	Contaminant
Formamide (DEAF)	Non-Corrosive	Contaminant/Degradation
THEED	Potentially Corrosive	Degradation
Bis-HEP	Non-Corrosive	Degradation
MEA	ASCC Concerns	Degradation
Bicine	Potentially Corrosive	Degradation
Polymeric Material	Non-Corrosive	Degradation

**DEA Solvent Quality Management With Merchant Reclaiming Options  
Vacuum Distillation, Ion Exchange, Electrodialysis**

Control of HSS	All
Control of DEAF (Slip-Stream Processing)	All
Control of DEAF (Batch Processing)	Vacuum Distillation Only
Control of THEED	Vacuum Distillation Only
Control of bis-HEP	Vacuum Distillation Only
Control of MEA	Vacuum Distillation Only*
Control of Bicine	Ion Exchange - Partial Vacuum Distillation
Control of Polymeric Material	Vacuum Distillation Only

Best Efficiency = Batch Processing

\*Developmental Efforts Underway

**MDEA Contamination/Degradation In TGTU Service**

HSS	Potentially Corrosive	Contaminant
MMEA	Non-Corrosive	Degradation
DEA	Non-Corrosive	Degradation
Bicine	Corrosive	Degradation
HE-Sarcosine	Corrosive	Degradation
Polymeric Material	Non-Corrosive	Degradation

**MDEA Solvent Quality Management With Merchant Reclaiming Options  
Vacuum Distillation, Ion Exchange, Electrodialysis**

Control of HSS	All
Control of MMEA	Vacuum Distillation Only*
Control of DEA	Vacuum Distillation Only*
Control of Bicine	Ion Exchange - Partial Vacuum Distillation
Control of HE-Sarcosine	Ion Exchange - Partial Vacuum Distillation
Control of Polymeric Material	Vacuum Distillation Only

Best Efficiency = Batch Processing

\*Developmental Efforts Underway

**MDEA Contamination/Degradation In Refinery Service**

Special considerations based on whether generic or formulated. The compounds measured in the residue should be listed under the various amine listed here

## Appendix 4

### Glossary

<b>Ash</b>	Ash is the portion of the sample that will not burn, therefore being the inorganic portion of the sample. This would include the strong cations, inorganic HSS anions, metals, etc.
<b>Bound Amine</b>	This is the amine that is bound by a HSS anion.
<b>Calculated Value</b>	A value that may easily be calculated using the analytical results of the sample. Bound amine is an example of a value that may be measured directly or by calculation using the total HSS anions and the total strong cations in solution.
<b>Contaminants</b>	Contaminants are items that enter the process that “pollute” the amine. These items would generally include solids/particulates, hydrocarbon, process chemicals, strong cations (sodium) and HSS (from their precursors entering with the gas).
<b>Control Target/Guideline</b>	These are industry-recognized guidelines for proper solvent quality. Ranges for certain compounds are set to ensure a reasonable level of reliability.
<b>DEA Fragments</b>	These are compounds that are the result of DEA degradation when the DEA molecule is broken down into simpler compounds. These items would include MEA, Bicine, and C2+ HSS anions.
<b>Degradation Products</b>	Degradation Products are items in solution that are derived from reactions with the base amine molecule.
<b>Direct Measurement</b>	Measuring a certain compound in the circulating solution with an analytical technique that directly measures the value of the compound.
<b>Free Amine</b>	This is the amount of amine available to participate in acid gas removal. May also be referred to as amine strength or alkalinity
<b>HSAS</b>	Heat Stable Amine Salt (HSAS) may also be referred to as Bound Amine, meaning this amine is bound by a HSS anion forming a Stable Amine Salt.
<b>HSS Anion</b>	A strong acid anion having higher acid strength than the acid gases being removed.
<b>MDEA Fragments</b>	These are the compounds that are the results of MDEA degradation when the MDEA molecule is broken down into simpler compounds. These items would include MMEA, DEA, HE-Sarcosine, Bicine, and C2+ HSS anions.
<b>Protonated Amine Molecule</b>	Acid gas removal is achieved by an acid base reaction with the amine molecule. When the amine is in a water solution, it becomes protonated (base) to react with the acid gas.
<b>Residue</b>	The total level of contaminants and degradation products in the solution.
<b>Sample Recovery</b>	A total material balance based on the bulk composition of the sample will show the sample recovery, meaning how much of the compounds in the sample may be accounted for. This number is then compared to 100% to see how complete of an analysis was done.
<b>Speciated HSS</b>	A breakdown of the total HSS anion level into its individual components or “species (formate, acetate, etc.) The total level of HSS anions may be measured in bulk or may be speciated to see the profile of the acid anions. These speciated anions are then also then grouped into organic and inorganic HSS anions. This is done to see if there are further concerns for solvent degradation, and certain anions may also have specific control points.
<b>Strong Cation</b>	Typically Sodium or Potassium in the gas treating solution.
<b>Total Amine</b>	This is the amount total amine in the sample, which is the sum of the free

	amine, and the bound amine.
--	-----------------------------